

# PROGRAM GUIDE ICONS



The HD icon appears next to a show that is playing in High Definition.



The New Show icon appears next to the latest broadcast of that show.



The Blocked Channel Icon appears next to a channel that is blocked by LISCO or with parental controls.



The Single Autotune icon appears next to a show you've set to Autotune



The Series Autotune icon appears next to a series of shows you've set to Autotune



The Recording icon appears next to a show that is recording or set to record.



The Series Recording icon appears next to a series of shows you've set to record.



The Canceled Recording icon appears next to a show that was previously selected to record to DVR but has been cancelled.



The Canceled Series Recording icon appears next to a series of shows that was previously selected to record, but has since been cancelled by you.



The Single reminder icon appears next to a show you've set to remind you about.



The Series reminder icon appears next to a series of shows you've set to remind you about.

# INFO BAR

The screenshot shows a dark grey info bar with orange vertical dividers. On the left, it displays '1.93' in orange, '2. DIY' in white, '11:55 am' in white, a blue heart icon, and 'Subscribed' in blue. The center section shows '6. Sweat Equity' in blue, '11:55 am - 12:00 pm. TVY' in white, and a white description: 'Contemporary Landscape - A couple turn their dream house near the lake into a cont...'. On the right, it shows '3.' in orange, a blue TV icon, 'Live TV 4.' in white, 'Lifestyle 5.' in white, and '2009' in white.

- 1. Channel number you're currently viewing**
- 2. Channel call sign**
- 3. Channel information**
- 4. "Live TV" icon shows that you're watching live content and not something recorded from the DVR**
- 5. Show category**
- 6. Name of the program being viewed in the info bar.**